

**PROPOSED FIELD PROGRAM FOR PRIVATE SUPPLY WELL SAMPLING**

Sample Location	Sample Identification	Sampling Method	Analyses									
			VOCs (includes EDB)	PAHs	SVOCs	TAL Metals	Mercury	Cyanide	Hexavalent Chromium	Pesticides	PCBs	Dioxin/Furans
East Tank Farm Residential Wells	GW-01	Tap or Grab	1	1	1	1	1	1	1	1	1	1
	GW-02	Tap or Grab	1	1	1	1	1	1	1	1	1	1
	GW-03	Tap or Grab	1	1	1	1	1	1	1	1	1	1
	GW-04	Tap or Grab	1	1	1	1	1	1	1	1	1	1
North of East Tank Farm Residential Wells	GW-05	Tap or Grab	1	1	1	1	1	1	1	1	1	1
	GW-06	Tap or Grab	1	1	1	1	1	1	1	1	1	1
	GW-07	Tap or Grab	1	1	1	1	1	1	1	1	1	1
South of East Tank Farm Residential Wells	GW-08	Tap or Grab	1	1	1	1	1	1	1	1	1	1
	GW-09	Tap or Grab	1	1	1	1	1	1	1	1	1	1
	GW-10	Tap or Grab	1	1	1	1	1	1	1	1	1	1
East Tank Farm Private Wells Not In Use	GW-11	Tap or Grab	1	1	1	1	1	1	1	1	1	1
	GW-12	Tap or Grab	1	1	1	1	1	1	1	1	1	1
Lorraine Process Area Church Well	GW-13	Tap or Grab	1	1	1	1	1	1	1	1	1	1
North Tank Farm Residential Well	GW-14	Tap or Grab	1	1	1	1	1	1	1	1	1	1
Piezometers - GW migration	1 through 10	Grab	10	10	10	10	10	10	10	10	10	10
<b>Total Investigation Tap Samples</b>			<b>24</b>	<b>24</b>	<b>24</b>	<b>24</b>	<b>24</b>	<b>24</b>	<b>24</b>	<b>24</b>	<b>24</b>	<b>24</b>
Field duplicate	1 per 10 samples		3	3	3	3	3	3	3	3	3	3
MS/MSDs	1 per 20 samples		2	2	2	2	2	2	2	2	2	2
<b>Total Private Supply Well Samples</b>			<b>29</b>	<b>29</b>	<b>29</b>	<b>29</b>	<b>29</b>	<b>29</b>	<b>29</b>	<b>29</b>	<b>29</b>	<b>29</b>
<b>Water QC Samples</b>												
Trip blanks	1 per cooler containing equipment		1	0	0	0	0	0	0	0	0	0
Equipment blanks	1 per day per set of for nondedicated		0	0	0	0	0	0	0	0	0	0
<b>Total Water QC Samples Associated with Private Supply Well Sampling</b>			<b>1</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>	<b>0</b>

NOTES:

Wilcox Oil Company  
Bristow, Creek County, Oklahoma  
Sampling and Analysis Plan  
Revision 00